

DIY | HOW TO APPLY Enviro Shield

Versatile • Easy to Use • Long Lasting

Restore and protect your driveway with Enviro Shield pavement rejuvenator. Easy DIY application, matt black finish, and long-lasting waterproof protection.

STEP 1: Prepare

- > Remove loose material (including weeds), and sweep dust from the surface
- > Cracks larger than 2mm should be repaired prior to Enviro Shield application
- > Ensure the surface is dry before applying product
- > Check that there is no forecasted rain for the day
- > One (1) coat of Enviro Shield is enough to rejuvenate the surface
- > Keep the lid on the product bucket to keep the product stable
- > Wear appropriate safety gear during application process to reduce the risk of product contact on skin (e.g. gloves, gumboots, and safety glasses)

What do you need?

- > Gloves
- > Gumboots
- > Safety glasses
- > Paint Roller
- > Flat stirrer stick

STEP 2: Application

Ideal temperatures for Enviro Shield application is between 10°C and 25°C. If application is outside of these temperatures, drying time will vary.

- > Mix Enviro Shield product in the bucket with a flat stirrer prior to application
- > Pour a small amount of Enviro Shield onto the surface (we recommend amounts of <500ml at a time)
- > Distribute Enviro Shield by spreading with a roller - Ensure the surface is evenly and lightly coated



STEP 3: Drying

- > Leave the applied Enviro Shield to cure until it is touch-dry (a minimum of four (4) hours).
- > Do not walk/drive over the surface during this time.

STEP 4: Clean Up

- > Clean equipment in warm soapy water
- > Pack and dispose of paint roller sleeve in general waste
- > We recommend De-Solve-It (or any solvent) to clean any unwanted cured Enviro Shield